



STABILIZER EXPLODED VIEW

| | |
|--------|----------------------------------|
| 75T1-1 | HORIZONTAL STABILIZER TIP RIB |
| 75T1-2 | HORIZONTAL STABILIZER NOSE RIB |
| 75T1-3 | HORIZONTAL STABILIZER REAR RIB |
| 75T1-4 | HORIZONTAL STABILIZER FRONT SPAR |
| 75T1-5 | HORIZONTAL STABILIZER REAR SPAR |
| 75T2-1 | F. & R. SPAR UPPER DOUBLERS |
| 75T2-2 | FRONT SPAR LOWER DOUBLER |
| 75T2-3 | REAR SPAR LOWER DOUBLER |
| 75T2-4 | HORIZONTAL STAB. FRONT BRACKET |
| 75T2-5 | HORIZONTAL STAB. REAR BRACKET |
| 75T2-6 | HOR. STAB. O/B HINGE BRACKET |
| 75T2-7 | HOR. STAB. CENTER HINGE BRACKET |
| 75T2-8 | HOR. STAB. CENTER HINGE GUSSET |
| 75T4-1 | STABILIZER SKIN |

STOL
CH 750

HORIZONTAL STABILIZER
EXPLODED VIEW

75-TX-1

copyright © 2008 CHRIS HEINTZ

zenithair.com

DATE: 05/09